

therapod™



Name _____

Dept _____

Location _____

Serial No _____

Therapod chairs and how
to make the most of the controls

Armrests may be adjusted to your required height.




Unzip the back cover to reveal the elastic straps. Adjust the tension in each of the four velcro fastened straps until the back rest contours your back and sides with a snug comfortable fit.



Raise to maximum height, then lower to lowest point. Move the back up to fit curve of your spine.

Back Adjustment

Support Adjustment



therapod™

Advanced Synchronised Mechanism



A

Gas Height Adjustment

A: Lift to adjust height of chair.



B

Tension Adjustment

B: To adjust tension of the mechanism, pull out handle, rotate lever clockwise to increase tension or anti-clockwise to decrease tension.



C

Seat Slider Adjustment

C: Lift and slide seat to desired depth and release to lock in position.



D

Locking Tilt Control

D: Twist level clockwise to unlock chair tilt function, anti clockwise to lock in place.

Note: All instructions are taken from the seated position